



IBM ThinkPad T42 Speakers Replacement

Written By: Gerald Watanabe



INTRODUCTION

Instructions to take out built in speakers inside the laptop.



TOOLS:


- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Rear Cover



- Unscrew the following screws on the underside of the T42.
- Note: for ease of reassembly, keep track of which screws go where.

Step 2





- Unscrew the 4 screws on either side of the rear end of the laptop.

Step 3 — Keyboard and Trackpad




- Flip the laptop over and open the display carefully - the keyboard, palm rest and bezel will be loose.

Step 4




- Maneuver the palm rest away from the keyboard carefully, both the keyboard and palm rest/trackpad will come off together.
- ****WARNING**** Both the keyboard and trackpad have connectors to the motherboard. Disconnect these before completely removing either component.

Step 5 — Lower Bracket




- The bracket will be free to move.

Step 6




- Remove the bracket.

Step 7




- Then remove the small rubber piece covering the microphone.

Step 8 — Speakers



- This component is free to move.

Step 9



- Disconnect its connector and pull it out carefully.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-07 05:14:46 PM.